


Rough openings

Welded Hollow Metal Frames (2" Face)

- Single Swing Door 1 = Door Width + 4 1/2"
2 = Door Height + 2 1/2"
- Double Swing Door 1 = Both Leaves' Width + 4 1/2"
2 = Door Height + 4 1/2"

Pocket Door (Using Johnson 1500 Track)

- Single Door 1 = Door Width x 2 + 1"
2 = Door Height + 4 1/2"
- Converging Door 1 = Both Leaves' Width x 2"
2 = Door Height + 4 1/2"



Knock Down Hollow Metal Dry Wall Frames (2" Face)

- Single Swing Door 1 = Door Width + 2"
2 = Door Height + 1"
- Double Swing Door 1 = Both Leaves' Width + 2"
2 = Door Height + 1"

Knock Down Timely Frames

- Single Swing Door 1 = Door Width + 1 1/4"
2 = Door Height + 1"
- Double Swing Door 1 = Both Leaves' Width + 1 1/4"
2 = Door Height + 1"

Knock Down Wood Frames

- Single Swing Door 1 = Door Width + 2 1/2"
2 = Door Height + 1 1/4"
- Double Swing Door 1 = Both Leaves' Width + 2 1/4"
2 = Door Height + 1 1/4"